



Acer Aspire One 722 Hard Drive Replacement

A guide on how to replace the hard drive on the Acer Aspire One 722.

Written By: Christian Barboza



Step 1 — Battery



- Shut the netbook off (Power down netbook at top left corner).

Step 2



- Close the netbook and flip it over so that the back is facing up.

Step 3



- Slide the button below the battery to the right while simultaneously pulling the battery out.

Step 4



- Remove the old battery and get the replacement battery.

Step 5



- Check the thin grooves on the side of the battery entry and line the replacement battery up to that.

Step 6 — Hard Drive




- Remove the screw on the bottom of the netbook.

Step 7




- Remove the backing plate.

Step 8




- Unscrew the four screws that are holding the hard drive in place.

Step 9



- Slowly lift the hard drive up and remove the sata cable that is connected to it.

Step 10



- Take your replacement hard drive and connect the sata cable to the hard drive.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 10:51:16 AM.